



TP-LD53

Product Manual

Triple Power



Scan for Latest (Updated)
Manual

STATEMENT

Copyright

Copyright © FRONUS SOLAR ENERGY (WASIQ TRADERS). All rights reserved.

No part of this manual may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means without the prior written permission of FRONUS SOLAR ENERGY (WASIQ TRADERS).

Trademarks



and other symbol or design (brand name, logo) that distinguishes the products or services offered by FRONUS has been trademark protected. Any unauthorized use of above stated trademark may infringe the trademark right.

Notice

All or part(s) of the products, features and services described in this document may not be within your scope of purchase or usage. Unless otherwise specified in the contract, the contents, information and recommendations in this document are provided as is, FRONUS makes no kind of warranties, guarantees or representations expressly or implicitly.

The content of the documents is continually reviewed and amended, where necessary. However, discrepancies cannot be excluded. FRONUS reserves the right to make improvements or changes in the product(s) and the program(s) described in this manual at any time without the prior notice.

The images contained in this document are for illustrative purposes only and may vary depending on product models.

Please visit the website WWW.FRONUS.COM of FRONUS SOLAR ENERGY (WASIQ TRADERS). for more information.

FRONUS reserves all the right for the final explanation.

About This Manual

Scope of Validity

This manual is an integral part of T-BAT Series. It describes the installation, electrical connection, commissioning, maintenance and troubleshooting of the product. Please read it carefully before operating.

Battery Module
TP-LD53

Note:

In the case of floor mounting, it contains battery module(s) only. In the case of wall mounting, it contains battery module(s) and wall bracket(s). For details, please refer to the Chapter 11 [“Technical Data”](#).

Target Group

The installation and maintenance can only be performed by qualified personnel who

- Are licensed and/or satisfy state and local jurisdiction regulations.
- Have good knowledge of this manual and other related documents.

Conventions

The symbols that may be found in this manual are defined as follows.

Symbol	Description
 DANGER	Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
 WARNING	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
 CAUTION!	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE!	Provides tips for the optimal operation of the product.

Table of Contents

1	Safety	1
1.1	General Safety	1
1.2	General Safety Precautions	2
1.3	Battery Handling Guide.....	2
1.4	Response to Emergency Situations.....	3
2	Product Overview	5
2.1	System Description	5
2.2	Appearance, Weight and Dimensions	5
2.2.1	Label.....	7
2.2.2	Electrical Connection Area	8
2.2.3	Indicator Panel	11
2.3	Symbols on the Label.....	15
2.4	Features	16
2.5	Certifications.....	16
3	Transportation and Storage	17
4	Preparation before Installation.....	19
4.1	Selection of Installation Location	19
4.1.1	Environment Requirement	19
4.1.2	Installation Carrier Requirement.....	20
4.1.3	Clearance Requirement	21
4.2	Tools Requirement.....	23
4.3	Additionally Required Materials	23
5	Unpacking and Inspection	24
5.1	Unpacking.....	24
5.2	Scope of Delivery.....	25
6	Mechanical Installation	27
6.1	Installation Options.....	27
6.2	Installation Procedure	28
6.2.1	Floor Mounting	29
6.2.2	Wall Mounting	35
7	Wiring.....	44
7.1	Details of Cables	44
7.2	PE Connection	45

7.3	Communication Connection.....	47
7.4	Ring Terminal Installation.....	48
7.5	Female Connector Installation.....	49
7.6	Wiring Procedure.....	52
7.6.1	The Right Electrical Connection Area of the Battery Module Selected to Be Connected to the Inverter.....	53
7.6.2	The Left Electrical Connection Area of the Battery Module Selected to Be Connected to the Inverter.....	60
8	System Commissioning	67
8.1	Checking before Power-on.....	67
8.2	Powering on/off the System.....	67
9	Troubleshooting and Maintenance	69
9.1	Troubleshooting.....	69
9.2	Maintenance.....	73
10	Decommissioning.....	74
10.1	Disassembling the Battery	74
10.2	Packing.....	76
10.3	Disposing of the Rechargeable Battery.....	76
11	Technical Data	77

1 Safety

1.1 General Safety

The series rechargeable battery is well designed and tested to meet all applicable states and international safety standards. However, like all electrical and electronic equipment, safety precautions must be observed and followed during the installation of the rechargeable battery to reduce the risk of personal injury and to ensure a safe installation.

Before installing the device, carefully read, fully understand and strictly follow the detailed instruction of the *User Manual* and other related regulations. And the safety instructions in this document are only supplements to local laws and regulations.

FRONUS shall not be liable for any consequences caused by the violation of the storage, transportation, installation, and operation regulations specified in this document, including, but not limited to:

- Rechargeable battery damage due to force majeure, such as earthquake, flooding, thunderstorm, lighting, fire hazard, volcanic eruption, overvoltage, etc.
- Rechargeable battery damage due to man-made cause
- Rechargeable battery used or operated against any items in local policy
- Failure to follow the operation instructions and safety precautions on the product and in this document
- Installation and use under improper environment or electrical condition
- Unauthorized modifications to the product or software
- Rechargeable battery damage caused during transportation by the customer
- Storage conditions that do not meet the requirements specified in this document
- Failure to adequately maintain the equipment. An on-site inspection should be carried out by a qualified technician after 120 months of continuous use. If more than 120 months have been passed since the date of commissioning, or the user cannot prove that the equipment has been adequately maintained
- Use of incompatible inverters or devices
- Installation and commissioning operated by unauthorized personnel who are not licensed and /or satisfy state and local jurisdiction regulations.

1.2 General Safety Precautions

- Overvoltage or wrong wiring may damage the battery module and cause combustion which may be extremely dangerous;
- Leakage of electrolytes or flammable gas may be occurred due to any type of product breakdown;
- Do not install the battery module in places where flammable and combustible materials are stored, and in which an explosive atmosphere is present;
- The battery module wiring must be carried out by qualified personnel;
- Battery module must be serviced by qualified personal;
- Ensure that the grounding cable is connected before handling the battery module.

1.3 Battery Handling Guide

Do's

- DO keep the battery module away from flammables materials, heat sources, and water sources;
- DO keep the battery module out of reach of children and animals;
- DO practice proper battery storage by keeping the battery module in a clean environment, free of dust, dirt and debris;
- DO store the battery module in a cool and dry place;
- DO seal the outer cable connection hole to prevent ingress of foreign objects;
- DO confirm that the wiring of the device must be correct;
- DO install the device according to the local standards and regulations.

Don'ts

- DON'T expose the battery module to an open flame, or the temperature in excess of 140°F/60°C;
- DON'T store or install the battery module in direct sunlight;
- DON'T install or operate the battery module in places where there is excessive moisture or liquids;
- DON'T place the battery module in a high-voltage environment;
- DON'T disconnect, disassemble or repair the device by unqualified personnel. Only a qualified personnel is allowed to handle, install and repair the device;
- DON'T damage the device by dropping, deforming, impacting, cutting or

penetrating with a sharp object. Otherwise, it may cause a fire or leakage of electrolytes;

- DON'T touch the device if liquid spill on it. There is a risk of electric shock;
- DON'T step on the packaging or the device may be damaged;
- DON'T place any objects on top of the battery module;
- DON'T charge or discharge a damaged battery module;
- DON'T dispose of the battery module in a fire. It may cause leakage or rupture;
- DON'T mix different types or makes of the battery module. It may cause leakage or rupture, resulting in personal injury or property damage.

1.4 Response to Emergency Situations

In case the battery module leaks electrolyte or any other chemical materials, or gas may be generated due to the leakage of battery module, be sure to avoid contact with the discharge at all times. In case of accidentally coming into contact with them, please do as follows:

- In case of inhalation: Leave the contaminated area immediately, and seek medical attention at once;
- In case of contact with eyes: Rinse eyes with running water for 15 minutes, and seek medical attention;
- In case of contact with skin: Wash the contacted area thoroughly with soap, and seek medical attention;
- In case of ingestion: Induce vomiting, and seek medical attention.

If a fire breaks out where the battery module is installed, please do as follows:

- In case the battery module is charging when the fire breaks out, provide it is safe to do so, disconnect the battery module circuit break to shut off the power charge;
- In case the device is not on fire yet, use a Class ABC fire extinguisher or a carbon dioxide extinguisher to extinguish the fire;
- If the battery module catches fire, do not try to put out the fire, and evacuate immediately.
- The battery module may catch fire when it is heated above 302°F/60°C; and in case of catching fire, it will produce noxious and poisonous gas, DO not approach and keep away.

Effective ways to deal with accidents

- In case of the damaged battery module, place it into a segregated place, and call the local fire department at the place where the user lives or qualified personnel.
- If any part of the battery module, or wiring is submerged, DO stay out of the water and DON'T touch anything; If the battery module gets wet, DON'T touch it.
- If the battery module is damaged, DON'T use it. Otherwise, it may result in both personal injury and property damage.
- DON'T use the submerged battery module again, and contact the qualified personnel for assistance.
- DO contact FRONUS immediately for assistance if the user suspects that the battery module is damaged.

WARNING!

- Do not crush or impact battery, and always dispose of it according to relevant safety regulations.
- The battery module may catch fire when heated above 150°C/302°F.
- In case of catching fire, the battery module will produce noxious and poisonous gases, and please keep away the battery.
- Damaged batteries may leak electrolyte or produce flammable gas. If users suspect that the battery is damaged, please immediately contact FRONUS for advice and information.
- All operations of T-BAT-SYS-LD relating to electrical connection and installation must be carried out by qualified personnel.

CAUTION!

- If the battery module is not installed within a month after receipt, it must be charged for maintenance. Non-operational batteries should be discarded according to the local regulations.

2 Product Overview

⚠ WARNING!

- The bi-directional energy storage inverter connected with the battery module must be an isolated inverter.

2.1 System Description

The battery system consists of one or more rechargeable batteries. A battery module is a type of electrical battery which can charge or discharge loads.

There are two installation options, such as floor mounting and wall mounting, that a user can select from.

2.2 Appearance, Weight and Dimensions

Appearance




Figure 2-1 Appearance

Table 2-1 Description of appearance

Item	Description
"Label"	Including performance label, which clearly identifies the device type, serial number, parameters, certification, etc., and manufacturer label describing name and address of manufacturer.
Electrical connection area	Including BAT +/BAT- ports, communication port, BMS port, grounding port, DIP, and POWER button. Please refer to "Electrical Connection Area" for details.
Indicator panel	Provide a human-readable indication of an instrument signal. For details, please refer to "Indicator Panel" .
Handle	Lift the battery conveniently.

Weight and Dimensions

Table 2-2 Weight and dimensions of a battery module

	Battery Module (TP-LD53)
Length (mm)	430
Width (mm)	150
Height (mm)	645
Net weight (kg)	48




Figure 2-2 Dimension: Battery module (TP-LD53)

2.2.1 Label

Some kinds of labels, such as a performance label, a manufacturer label, etc., should be pasted on the battery module. The above-mentioned labels are located on the right side of the battery module. For example, the performance label consists of the following parts:





Figure 2-3 Label

Regarding the **SN**, 32-base nomenclature is adopted to identify the type, specific features, manufacture date, order serial number, and factory serial number of a battery module.

32-base Nomenclature



1 0-2023, 1-2024, 2-2025 A-2033, B-2034

2 The two digits represent the week of when the battery module was produced. There are totalling 52 weeks in a year, and the first week is represented by the number 00, and the second week is represented by the number 01. Do the rest in the same manner in accordance with the 32-base coding rule.

2.2.2 Electrical Connection Area




Figure 2-4 Right side of battery module

Table 2-3 Description of ports and keys

Item	Description
A	Power button: Start/shut down system.
B	BAT+/BAT- port: Connect to the BAT+/BAT- port of the inverter or the adjacent battery module.
C	“DIP Switch” : Realize battery's parallel function (a reserved function).
D	“BMS” port: Connect to the “BMS” port on the inverter. Or, it shall be covered by a waterproof plug if it is not connected.
E	Breather valve: To balance the pressure differentials inside and outside a battery module.
F	Grounding port: Connect to the grounding port of the battery module or BMS.
G	COM2 port: Connect to the COM1 port of the neighbouring battery module (if any). Or, it shall be covered by a waterproof cap if it is not connected.




Figure 2-5 Left side of battery module

Table 2-4 Description of ports

Item	Description
A'	BAT+/BAT- port: Connect to the BAT+/BAT- port of the inverter or the adjacent battery module
B'	"BMS" port: Connect to the "BMS" port of the inverter, or it doesn't need to be connected. Or, it shall be covered by a waterproof plug if it is not connected.
C'	COM1 port: Connect to the COM2 port of the adjacent battery module (if any). Or, it shall be covered by a waterproof cap if it is not connected.
D'	Grounding port: Connect to the grounding port of the neighbouring battery module.

DIP Switch

A DIP Switch is actually a set of small manual electronic switches that are designed to be packaged with other circuits. It is currently equipped with the battery module.

The location of the DIP switch and the factory defaults are shown as below.




Figure 2-6 DIP Switch




Figure 2-7 Default configuration

NOTICE!

- In the case of one tower, there is only one master battery module (always the uppermost battery module). While the master battery module connects to the inverter, **please confirm that the DIP switch 5 must stay in the ON position**, as well as the DIP switch 5 on the rest of the battery modules in the ON positions. Usually, the DIP switch 5 will be slid to the ON position in the factory settings.
- In the case of more than two towers, except that the master battery module (always the uppermost battery module) of the last tower shall be slid to the ON position, the Dip switch 5 on the rest of the master battery modules shall be flipped up to the OFF positions. Regarding the Dip switch 5 on the rest of the battery modules, please confirm that they are in the ON positions. Usually, the DIP switch 5 will be slid to the ON position in the factory settings.
- To adjust the DIP switch, a small flat-head screwdriver should be prepared by the users themselves. **Do not use a pencil.** Graphite from the pencil is conductive and may damage the DIP switch.

2.2.3 Indicator Panel

The battery module is equipped with a monochrome status light (blue) and five tri-colour SOC power indicators (green/yellow/red) to show its operating status. The SOC power indicators show the current battery percentage.




Figure 2-8 Indicators

Table 2-5 Description of indication


LED	Colour	State	Indication
Status light	Green	Flashing	Start up
SOC power indicators	Blue	Solid	
Status light	Yellow	Solid → Off	Shut down
SOC power indicators	Blue	Solid → Off	
Status light	Green	Solid	Standby
SOC power indicators	Blue	Solid	
Status light	Green	Flashing	Charging
SOC power indicators	Please refer to "Indicator information while charging" .		
Status light	Green	Flashing	Discharging
SOC power indicators	Please refer to "Indicator information while discharging" .		
Status light	Red	Flashing	Fault
SOC power indicators	Blue	Solid	
Status light	Please refer to "Black Start" .		Black Start
SOC power indicators			

NOTICE!

- The function of **Self Test** will be performed when users turn the system on, with a duration of 11 seconds. In the meantime, the status light will remain on solid yellow light, and the SOC power indicators will remain on solid blue light based on their actual remaining capacity.

Table 2-6 Indicator information while charging

SOC value	Status light	SOC1	SOC2	SOC3	SOC4	SOC5
LED colour	Green	Blue	Blue	Blue	Blue	Blue
0% = SOC	Flashing	Light off	Light off	Light off	Light off	Light off
0% < SOC < 20%	Flashing	Flash	Light off	Light off	Light off	Light off
20% ≤ SOC < 40%	Flashing	Flash	Flash	Light off	Light off	Light off
40% ≤ SOC < 60%	Flashing	Flash	Flash	Flash	Light off	Light off
60% ≤ SOC < 80%	Flashing	Flash	Flash	Flash	Flash	Light off
80% ≤ SOC ≤ 100%	Flashing	Flash	Flash	Flash	Flash	Flash



If the battery level is at 60%, the SOC power indicators will show as follows:

- The first three SOC power indicators (SOC1, SOC2 and SOC3) will flash blue light every 1 second;
- The remaining SOC power indicators (SOC4 and SOC5) will be off.

Figure 2-9 Charging

NOTICE!


- When the charging current is less than or equal to 1 A, the SOC indicators will remain on solid blue light.
- When the charging current is over 1 A, the SOC indicators will flash blue lights.

If more than two battery modules (including two) are purchased, the circumstance that some of the battery modules' SOC indicators may flash blue and the remaining battery modules' SOC indicators may remain on solid blue, may occur. The reasons for this circumstance are as follows:

- a. If the battery modules are charged fully, the SOC indicators will remain on solid blue light.
- b. If the battery modules are not charged fully, it indicates that the charging current is less than or equal to 1 A.

Table 2-7 Indicator information while discharging

SOC value	Status light	SOC1	SOC2	SOC3	SOC4	SOC5
LED colour	Green	Blue	Blue	Blue	Blue	Blue
SOC ≥ 80%	Flashing	Light on	Light on	Light on	Light on	Light on
SOC ≥ 60%	Flashing	Light on	Light on	Light on	Light on	Light off
SOC ≥ 40%	Flashing	Light on	Light on	Light on	Light off	Light off
SOC ≥ 20%	Flashing	Light on	Light on	Light off	Light off	Light off
SOC > 0%	Flashing	Light on	Light off	Light off	Light off	Light off
SOC = 0%	Flashing	Light off	Light off	Light off	Light off	Light off



If the battery level is at 60%, the SOC power indicators will show as follows:

- The first three SOC power indicators (SOC1, SOC2, and SOC3) will remain on solid blue light;
- The remaining SOC power indicators (SOC4 and SOC5) will be off.

Figure 2-10 Discharging

Black Start

The equipment can provide **Black Start** capacity, meaning that our energy storage inverter and battery can continue to run even if the power grid and photovoltaic panel are out of service. The startup procedure for **Black Start** is as follows:

- First stage: in case of pressing and holding the **POWER** button for less than 15 seconds, the status light will come on solid yellow light in the first 11 seconds and then turn to solid green light in the last 4 seconds, and the SOC power indicators will come on solid blue light based on the actual remaining capacity.
- Second stage: after pressing and holding the **POWER** button for more than 15 seconds, the status light will flash yellow light every 1 second, and all the SOC power indicators will remain on solid blue light based on the actual remaining capacity.
- Finally, release the **POWER** button.

2.3 Symbols on the Label

Table 2-8 Description of symbols

Symbol	Description
	CE mark. The rechargeable battery complies with the requirements of the applicable CE guidelines.
	TUV certified.
	The battery system must be disposed of at a proper facility for environmentally-safe recycling.
	The battery module may explode. The rechargeable battery can become hot during operation. Avoid contact during operation.
	Danger of high voltages. Danger to life due to high voltages in the rechargeable battery!
	Danger. Risk of electric shock!
	Observe enclosed documentation.
	The rechargeable can not be disposed together with the household waste.
	The rechargeable can not be disposed together with the household waste.
	Keep the battery system away from children.
	Keep the battery system away from open flames or ignition sources.

2.4 Features

The T-BAT-SYS-LD is one of the most advanced energy storage systems on the market today, using state-of-the-art technology, and having the characteristics of high reliability and convenient control. Characteristics are shown as follows:

- 90% DOD;
- 95% Battery Round-trip Efficiency;
- Cycle Life > 6000 Cycles;
- Secondary Protection;
- IP65 Protection Level and Protection Class I;
- Safety & Reliability;
- Small Occupied Area;
- Floor Mounting and wall mounting.

2.5 Certifications

BAT system safety	CE, IEC 62619, IEC 63056, IEC 62620, IEC 62477-1, IEC 60730 Annex H, IEC 60529, UN38.3
UN number	UN 3480
Hazardous materials classification	Class 9
UN transportation testing requirements	UN 38.3
International protection marking	IP65, Protection Class I

3 Transportation and Storage

If the rechargeable battery are not put into use immediately, the transportation and storage requirements needs to be met:

Transportation

- Observe the caution signs on the packaging of battery before transportation.
- Pay attention to the weight of the rechargeable battery. Be cautious to avoid injury when carrying battery module (TP-LD53). Regarding the actual number of installers, please strictly comply with the local laws and regulations where the user is located.
- Wear protective gloves when carrying the equipment by hand to prevent injuries.
- When lifting up the rechargeable battery, hold the handle position and the bottom position of the battery. Keep the rechargeable battery horizontal in case of falling down due to tilt.




Figure 3-1 Handle position of carton

Storage

- Do not remove the original packaging material and check the outer packaging material regularly.
- The required storage temperature: the service life may be up to 6 months in case the temperature is between 30°C and +50°C, or it may be up to 12 months in case the temperature is between -20°C and +30°C. See Table 3-1. Regarding charging interval, please refer to Chapter 9.2 ["Maintenance"](#).

Table 3-1 Storage temperature and time

Storage Temperature	Storage Time
30°C to 50°C	6 months
-20°C to 30°C	12 months

- The relative humidity should be between 5% and 95%.
- Stack the battery in accordance with the caution signs on the battery carton to prevent their falling down and device damage. Do not place it upside down.
- If the rechargeable battery has been stored for more than 1 year, it must be checked and tested by professionals before use.

4 Preparation before Installation

4.1 Selection of Installation Location


The installation location selected for the rechargeable battery is quite critical in the aspect of the guarantee of machine safety, service life and performance.

- It has the IP65 ingress protection, which allows it to be installed outdoor;
- Before installing the battery system, lay out available floor space or wall space including aisles for installation, maintenance and possible battery module replacement.

4.1.1 Environment Requirement

Make sure the installation site meets the following conditions:

- The operating temperature: -20°C to $+53^{\circ}\text{C}$;
- The humidity shall be between 5-95%;
- Do not install the rechargeable battery in the areas where the altitude exceeds 3000 m;
- Install the rechargeable battery in a well-ventilated environment for heat dissipation;
- Do not install the rechargeable battery in areas with flammable, explosive and corrosive materials;
- Do not install the rechargeable battery in areas near combustibles and antenna
- You are recommended to install an awning over it. Direct sunlight, rain exposure and snow laying up is not allowed.



4.1.2 Installation Carrier Requirement

The mounting location must be suitable for the weight and dimensions of the product and the support surface for installation must be made of a non-flammable material.

- Solid brick/concrete;
- Either floor mounting or wall mounting, the bearing capacity of the area to place or install a battery module must be over 200 kg;
- Please ensure that the thickness of any part of the wall should not be less than 100 mm;
- The device must not be installed on the wood wall.

4.1.3 Clearance Requirement

To guarantee proper heat dissipation and ease of disassembly, the minimum space around the rechargeable battery must meet the standards indicated below.

- No matter which floor mounting or wall mounting is chosen, a distance between 200 and 300 mm wide shall be provided from the wall to the edge of the battery module.
- No matter which floor mounting or wall mounting is chosen, a distance between 400 and 600 mm wide shall be provided from the left side edge of a battery module to the right side edge of the neighbouring battery modules.
- In the case of floor mounting, a distance of 55 mm shall be provided from the rear side of the battery module to the wall.
- In the case of wall mounting, the distance between 300 and 350 mm shall be provided from the grounding to the bottom of the battery module.




Figure 4-2 Clearance requirement about floor mounting




Figure 4-3 Clearance requirement about wall mounting

4.2 Tools Requirement

Installation tools include but are not limited to the following recommended ones. If necessary, use other auxiliary tools on site.



4.3 Additionally Required Materials

The following is a recommended list of equipment required for installation of the battery system.

Table 4-1 Additionally required wires

No.	Required Material	Type	Diameter/ Conductor Cross-section
1	Protective pipe	Corrugated pipe	External diameter: over 60 mm
2	Grounding cable	/	16 mm ²

5 Unpacking and Inspection

5.1 Unpacking

- The rechargeable battery undergoes 100% testing and inspection before shipping from the manufacturing facility. However, transport damage may still occur. Before unpacking the rechargeable battery, please verify that the model and outer packing materials for damage, such as holes and cracks.
- Unpacking the battery module according to the following figures. If there are other cartons, such as the rack carton, cabinet carton, cables carton, or cartons about wall mounting, the unpacking procedure can also be referred to the following figures.




Figure 5-1 Unpacking the battery module

- Be careful when dealing with all package materials which may be reused for storage and relocation of the rechargeable battery in the future.
- Upon opening the package, check whether the appearance of the rechargeable battery is damaged or lack of accessories. If any damage is found or any parts are missing, contact your dealer immediately.

5.2 Scope of Delivery

One Battery Module (TP-LD53)




Table 5-1 Packing list of battery module (TP-LD53)

Item No.	Description	Quantity (Unit: pc)
/	Battery module	1
/	Wall bracket	1
A	Power cable (orange) (2000 mm)	1
B	Power cable (black) (2000 mm)	1
C	Communication cable (2000 mm)	1
D	L-shaped wall bracket	2
E	Waterproof plug	2
F	Ring terminal	2
G	Expansion screw ¹	6
H	Expansion bolt ¹	4
I	Self-tapping screw ¹	4
J	M6*12 cross external hexagon screw ¹	4
K	Document	/

NOTICE!

- The above accessories kit applies to the installation options of both floor mounting and wall mounting.
- The above items are only for one battery module. Our company will provide corresponding components according to the battery modules.
- The accessory with the superscript "1" indicates that FRONUS will give the user two extra free accessories away.

Accessories Kit for Cables (for two adjacent battery modules)




Table 5-2 Packing list of accessories kit for cables

Item No.	Description	Quantity (Unit: pc)
A1	Female connector	2*
B1	Communication cable (1000 mm)	1
C1	Ring terminal	2

NOTICE!


- The above-mentioned accessories kit needs to be purchased separately.
- The accessory with the mark "*" indicates that there are 2 totalling plastic bags, with 1 piece in each bag.

6 Mechanical Installation

6.1 Installation Options

There are two installation options (floor mounting and wall mounting) are available, with details as follows:

Option A: Floor Mounting



Option B: Wall Mounting




Figure 6-1 Installation options

NOTICE!

- The Figure 6-1 takes two battery modules as an example.
- Both the floor mounting and the wall mounting may withstand up to sixteen battery modules.

6.2 Installation Procedure

WARNING!

- Only the qualified personnel can perform the mechanical installation following the local standards and requirements.
- Check the existing power cables or other piping in the wall to prevent electric shock or other damage.
- The bi-directional energy storage inverter connected with the battery module must be an isolated inverter.

CAUTION!

- Always be aware of the weight of the battery. Personal injuries may result if the battery is lifted improperly or dropped while being transported or mounted.
- Be sure you have all the proper protective clothing, safety tools, and equipment on hand before stating the installation.
- Keep the work area clean and well lit. Cluttered or dark areas invite accidents.

NOTICE!

- Both the floor and wall mounting may withstand up to sixteen battery modules.

Table 6-1 Number of battery module

	Floor mounting	Wall mounting
Max. number of battery modules	16	16

- Either the floor or wall mounting, the bearing capacity of the grounding or the wall, which enables it to bear the loads from the whole battery system, must be over 200 kg.

Table 6-2 Bearing capacity

	Floor mounting	Wall mounting
Bearing capacity of the supporting surface of a battery module	≥ 200 kg	≥ 200 kg

- Either the floor or wall mounting, the distance from the battery module to the wall, the neighbouring battery module, or the grounding shall be provided as below.

Table 6-3 Distance requirement

	Floor mounting	Wall mounting
Distance from the edge of the battery module to the wall	200 mm ~ 300 mm	200 mm ~ 300 mm
Distance from the back of the battery module to the wall	55 mm	55 mm
Distance from the edge of the battery module to the edge of the neighbouring battery module	400 mm ~ 600 mm	400 mm ~ 600 mm
Distance from the bottom of the battery module to the ground	/	300 mm ~ 350 mm

6.2.1 Floor Mounting

WARNING!

- The site for installing the battery module must be level (no slope, no pothole).

NOTICE!

- Allow sufficient clearance between adjacent walls or equipment for proper installation of the battery module.
- The following steps take one (1) battery module as an example.

Step 1: Fix the L-shaped wall bracket (Part D) to the battery module with M6*12 cross external hexagon screw (Part J) (× 2 pcs), but do not tighten them fully.




Figure 6-2 Fixing L-shaped wall bracket to the battery module

NOTICE!

- Do not tighten the screws fully.

Step 2: Locate the L-shaped wall bracket against the wall.




Figure 6-3 Locating the battery module against the wall

NOTICE!

- At least two persons are required to lift the battery module.

Step 3: Draw a circle along the inner ring, with one on each side. Then gently move the battery module aside.




Figure 6-4 Drawing circles

Step 4: Drill two holes at a depth of more than 60 mm in the concrete wall (or solid brick wall) by using a Drill (Ø8 mm).




Figure 6-5 Drilling holes

NOTICE!

- The battery module can only be installed on the concrete wall or the solid brick wall.
- To prevent angled holes from being drilled, it is suggested to use a Ø8 mm Drill to drill holes first, and then change to a Ø10 mm Drill.
- An electric drill dust collector is recommended.

Step 5: Insert the expansion bolt (Part H) (× 2 pcs) into the two holes.




Figure 6-6 Inserting expansion bolts

Step 6: Gently move the battery module against the wall, and align the holes drilled previously.

Correctly insert and tighten self-tapping screw (Part I) (× 2 pcs) to secure the L-shaped wall bracket on both sides to the wall (Tightening torque: 6-8 N·m).

Fully tighten the M6*12 cross external hexagon screw (Part J) (× 2 pcs) on both sides (Tightening torque: 4-5 N·m).




Figure 6-7 Tightening tapping screws and M6 screws

NOTICE!

- At least two persons are required to lift the battery module.

Step 7: Repeat steps 1 to 6 to install the second battery module, as well as the remaining battery modules (if any).




Figure 6-8 Installing the remaining battery module

NOTICE!

- The distance between 400 and 600 mm wide shall be provided from the left side edge of a battery module to the right side edge of the neighbouring battery module.
- Up to sixteen (16) battery modules can be installed in a straight line.

6.2.2 Wall Mounting

Step 1: Attach the wall bracket to the wall, and make sure that it is level via the cylindrical plastic bubble spirit level on the bracket.

Draw a circle along the inner ring, with a total of 4 circles.




Figure 6-9 Drawing circles

NOTICE!

- A distance between 300 and 350 mm from the bottom of the wall bracket to the ground must be reserved.

Step 2: Remove the wall bracket, and then drill four holes at a depth of more than 90 mm in the concrete wall (or solid brick wall) by using a Drill ($\varnothing 12$ mm).




Figure 6-10 Drawing holes

NOTICE!

- To prevent angled holes from being drilled, it is suggested to use a $\varnothing 10$ mm Drill to drill holes first, and then change to a $\varnothing 12$ mm Drill.
- Currently, the battery module can only be installed on the concrete wall or the solid brick wall.
- An electric drill dust collector is recommended.

Step 3: Attach the wall bracket to the wall again, and correctly insert and tighten expansion screw (Part G) (x 4 pcs) to secure the wall bracket (Tightening torque: 14-16 N·m).




Figure 6-11 Tightening expansion screw

NOTICE!

- Please make sure that it is level via the cylindrical plastic bubble spirit level on the wall bracket.

Step 4: Fix the L-shaped wall bracket (Part D) to the battery module with M6*12 cross external hexagon screw (Part J) (× 2 pcs), but do not tighten them fully.




Figure 6-12 Fixing L-shaped wall bracket to the battery module

NOTICE!

- Do not tighten the screws fully.

Step 5: Gently lift the battery module onto the wall bracket, and locate it against the wall bracket.




Figure 6-13 Lifting the battery module

NOTICE!

- At least two persons are required to lift the battery module.
- The battery module shall be located against the wall bracket.

Step 6: Draw a circle along the inner ring, with one on each side.
Then gently carry the battery module down to the ground.




Figure 6-14 Drawing circles

NOTICE!

- It needs a second person to hold the battery module to prevent it from falling from the wall bracket when installation.

Step 7: Drill two holes at a depth of more than 60 mm in the concrete wall (or solid brick wall) by using a Drill (Ø8 mm).




Figure 6-15 Drilling holes

NOTICE!

- Currently, the battery module can only be installed on the concrete wall or the solid brick wall.
- To prevent angled holes from being drilled, it is suggested to use a Ø8 mm Drill to drill holes first, and then change to a Ø10 mm Drill.
- An electric drill dust collector is recommended.

Step 8: Insert the expansion bolt (Part H) (x 2 pcs) into the two holes.




Figure 6-16 Insert expansion bolts

Step 9: Gently lift the battery module onto the wall bracket, and locate it against the wall bracket.

Correctly insert and tighten self-tapping screw (Part I) (× 2 pcs) to secure the L-shaped wall bracket on both sides to the wall (Tightening torque: 6-8 N·m).

Fully tighten the M6*12 cross external hexagon screw (Part J) (× 2) on both sides (Tightening torque: 4-5 N·m).




Figure 6-17 Tightening tapping screws and M6 screws

NOTICE!

- At least two persons are required to lift the battery module.

Step 10: Repeat steps 1 to 9 to install the second battery module, as well as the remaining battery modules (if any).




Figure 6-18 Installing the remaining battery module

NOTICE!

- The distance between 400 and 600 mm wide shall be provided from the left side edge of a battery module to the right side edge of the neighbouring battery modules.
- Up to sixteen (16) battery modules can be installed in a straight line.

7 Wiring


NOTICE!

- Regarding the PE and communication cable, of which one end connects to the inverter, it shall be made before conducting wiring.
- Regarding the power cable connecting two adjacent battery modules, the female connector onto the power cable must be made before conducting wiring.

7.1 Details of Cables

Cables in the Accessories Kit for Battery Module

Table 7-4 Details of cables

Cable	Length	Purpose	Qty
 Power cable (black)	2000 mm	There are two terminals at both ends: one connects to the "BAT-" port of a battery module, and the other connects to the "BAT-" port of the inverter.	1 pc
 Power cable (orange)	2000 mm	There are two terminals at both ends: one connects to the "BAT+" port of a battery module, and the other connects to the "BAT+" port of the inverter.	1 pc
 Communication cable	2000 mm	There are two terminals at both ends: one connects to the "BMS" port of a battery module, and the other connects to the "BMS" port of the inverter.	1 pc

Cables in the Accessories Kit for Cables (for two adjacent battery modules)

NOTICE!

- The cables in the following table are delivered with the Accessories Kit for Cables, which needs to be purchased separately.

Table 7-5 Details of cables

	There are two terminals at both ends: one connects to the "COM1" port of the battery module, and the other connects to the "COM2" port of the adjacent battery modules.	1 pc
Communication cable 1000 mm		

7.2 PE Connection

The steps for making PE connection are shown as follows:

Step 1: Strip the cable jacket about 12 to 15 mm from the end.




Figure 7-1 Stripping cable jacket

Step 2: Cut the heat-shrink tubing to about 28 to 30 mm long, carefully slide it onto the end of the cable, and then carefully slip the wires all the way into the ring terminal (Part F).




Figure 7-2 Cutting heat-shrink tubing

Step 3: Crimp the terminal, and heat the heat-shrink tubing after it wraps the end of terminal.




Figure 7-3 Crimping and heating

Step 4: Unscrew the M5 screw, and then connect the assembled grounding cable to the grounding port of the battery module, and then tighten M5 screw (Tightening torque: 2.5-3 N·m).




Figure 7-4 Tightening M5 screws

NOTICE!

- Regarding the grounding cable that is prepared by the user, a wire size of 16 mm² for the cable is recommended.

7.3 Communication Connection

To ensure normal operation between the battery module and inverter, the communication cable connecting from the battery module to the inverter is required to connect RJ45 connector.

Make sure that the "BMS" port on the battery module connects to the inverter is Pin to Pin. The "BMS" port pin assignment is shown as follows:

Table 7-1 "BMS" port pin assignment

PIN	1	2	3	4	5	6	7	8
BMS	RS485B	RS485A	GND	CAN-H	CAN-L	12V-OUT	MASTER-IN	/

The wire sequence of one terminal connecting to the inverter is the same as the wire sequence of the other terminal, connecting to the battery module.

The wire sequence is shown as follows:




Figure 7-5 Wire sequence

The steps for making RJ45 connector to communication cable (Part C) are shown as follows:

- Step 1:** Strip the cable jacket about 15 mm down from the end.
- Step 2:** Carefully insert the wires all the way into the RJ45 connector, making sure that each wire passes through the appropriate guides inside the connector.
- Step 3:** Push the RJ45 inside the crimping tool and squeeze the crimper all the way down.




Figure 7-6 Making RJ45 connector to communication cable

NOTICE!

- The communication cable shall have a shield layer.
- The communication cable is delivered with the Accessories Kit for Cables.

7.4 Ring Terminal Installation

Ring terminals are connectors for power cables. They are designed to connect the end of a power cable to a circuit point.

To connect the power cable to the circuit point on the inverter, a ring terminal is required to be fit over the power cable. The installation procedure of ring terminal onto the power cable is shown as follows:

Step 1: Take out the power cables (Parts A and B), and with care, strip the cable jacket about 10 mm from the end.




Figure 7-7 Stripping power cable

NOTICE!

- DO NOT damage the conductor while sliding the jacket off the power cable end.

Step 2: Fit the ring terminal over the conductor strands, and squeeze the crimping tool to crimp the terminal.




Figure 7-8 Crimping terminal

NOTICE!

- Properly place the ring terminal into the MC4 crimping tool.

Step 3: Make the positive power cable according to the above two steps.




Figure 7-9 Making power cables

NOTICE!

- The ring terminals are delivered with the inverter's accessories kit.
- Please refer to the inverter's User Manual for further installation steps.

7.5 Female Connector Installation

A power cable consists of a flexible cord with connectors, male and female. Since the power cables provided are only attached to the male connector, the female connector must be installed onto the power cable by the user himself/herself before conducting wiring between battery modules. The installation procedure of female connector onto the power cable is shown as follows:

Step 1: Take out the power cables (Parts A and B), and connectors (Part A1) (including connector body, cable seal ring, and tail cover).




Figure 7-10 Taking out accessories

Step 2: Orderly insert the stripped wire into the tail cover and cable seal ring.




Figure 7-11 Inserting the stripped wire

Step 3: With care, strip the cable jacket about 15 ± 1 mm from the end.




Figure 7-12 Stripping cable jacket

NOTICE!

- DO NOT damage the conductor while sliding the jacket off the power cable end.
- The wire size of the power cable delivered with the accessories kit is 25 mm^2 (3 AWG).

Step 4: Fit the connector body over the conductor strands, and squeeze the crimper to crimp the terminal. The conductor strands exposed shall not be over 1 mm.




Figure 7-13 Fitting connector body and crimping terminal

NOTICE!

- Properly place the plastic housing into a hydraulic wire crimper.
- DO NOT place the conductor insulation into the connector body.
- DO NOT crush the plastic housing while crimping.
- DO NOT crush or damage the conductor insulation while crimping.

Step 5: Orderly push the cable seal ring and tail cover into the body. The sound of "Click" will be heard when the tail cover is properly plugged into the body.




Figure 7-14 Assembling connector

NOTICE!

- User should hear the sound of "Click" while pressing the tail cover into the location position.

Step 6: Make the positive power cable according to the above steps.




Figure 7-15 Making positive power cable

After finishing the installation of the female connector onto the power cable, and due to the special terminal connector on the power cable, please note the following details.




Figure 7-16 Lock button

NOTICE!

- The Figure 7-16 is the power cable that finishes the installation of the female connector.
- Press and hold the "Lock button" while unplugging the power cable. Otherwise, it cannot be pulled out.
- Don't violently remove the power cables when they are locked.

7.6 Wiring Procedure

WARNING!

- Only the qualified personnel can perform the wiring.
- Follow this manual to wire connection. The device damage caused by incorrect cabling is not in the scope of warranty.
- Inspect each terminal for visual signs of mechanical defects.

CAUTION!

- Use insulated tools and wear individual protective tools when connecting cables.
- Do not bend the power cable, particularly at the point where the cable joins the connector, at 90° while conducting wiring.
- When the cable insulation layer is chewed through, this can cause short circuits and potentially start an electrical fire. Therefore, where there is a risk of pests, rodents, or termites, protective barriers or additives are suggested to be added to the cables to prevent damage.

NOTICE!

- The electrical connection areas on both sides of the battery module are allowed to conduct wiring with the inverter.
- The wiring procedure applies to both floor mounting and wall mounting.

7.6.1 The Right Electrical Connection Area of the Battery Module Selected to Be Connected to the Inverter

Cable connection for only one battery module

Step 1: Connect the negative power cable to the "BAT-" ports of the battery module and inverter.

Connect the positive power cable to the "BAT+" ports of the battery module and inverter.

Connect the communication cable to the "BMS" ports of the battery module and inverter.

Cover the "COM2" port with a waterproof cap, and tighten it clockwise.

Make sure that power cables and communication cable are wired correctly, as shown in Figure 7-17. Failing to do so may cause severe damage to your battery module.

Table 7-2 Cable information

Cable	Length	Purpose (from battery module to inverter)	Qty
Communication cable	2000 mm	"BMS" port to "BMS" port	1 pc
Power cable (black)	2000 mm	"BAT-" port to "BAT-" port	1 pc
Power cable (orange)	2000 mm	"BAT+" port to "BAT+" port	1 pc




Figure 7-17 Cable connection of the right electrical connection area

NOTICE!

- Regarding the making process of grounding cable, please refer to "[PE Connection](#)".
- Regarding the making process of communication cable, please refer to "[Communication Connection](#)".
- A sound of "Click" should be heard while plugging in the power cables. It indicates that the cable connectors are properly plugged into the ports.
- The waterproof cap has been covered before delivery.
- Don't violently remove the power cables when they are locked.

Step 2: Cover "BAT+" and "BAT-" ports with waterproof plugs (Part E), as well as "BMS" and "COM1" ports with waterproof caps.




Figure 7-18 Left electrical area of the battery module

Tip: Use safety gloves when connecting battery modules.

Cable connection for two or more battery modules

Since the wiring procedure of two battery modules is the same as that of more than two battery modules, the wiring procedure of two battery modules is taken as an example.

The general wiring diagram of two battery modules is shown below:




Figure 7-19 Wiring diagram of two battery modules

The detailed connection procedure is shown as follows:

Step 1: Connect the negative power cable to the "BAT-" ports of the battery module and inverter.

Connect the positive power cable to the "BAT+" port of the battery module and inverter.

Connect the communication cable to the "BMS" port of the battery module and inverter.

Cover the "COM2" port with a waterproof cap, and tighten it clockwise.

Make sure that power cables and communication cable are wired correctly, as shown in Figure 7-20. Failing to do so may cause severe damage to your battery module.

Table 7-3 Cable information

Cable	Length	Purpose (incl. from battery module to inverter, battery module to battery module)	Qty
Communication cable	2000 mm	"BMS" port to "BMS" port	According to the actual number of the battery modules
Power cable (black)	2000 mm	"BAT-" port to "BAT-" port	
Power cable (orange)	2000 mm	"BAT+" port to "BAT+" port	




Figure 7-20 Cable connection of the right electrical connection area

NOTICE!

- Regarding the making process of grounding cable, please refer to "[PE Connection](#)".
- Regarding the making process of communication cable, please refer to "[Communication Connection](#)".
- A sound of "Click" should be heard while plugging in the power cables. It indicates that the cable connectors are properly plugged into the ports.
- The waterproof cap has been covered before delivery.
- Don't violently remove the power cables when they are locked.

Step 2: Connect the negative power cable to the "BAT-" ports of adjacent battery modules.

Connect the positive power cable to the "BAT+" ports of adjacent battery modules.

Connect the communication cable (Part B1) to the "BMS" ports of adjacent battery modules.

Cover the "BMS" ports of adjacent battery modules with waterproof caps, and tighten them clockwise.

Make sure that power cables and communication cable are wired correctly, as shown in Figure 7-21. Failing to do so may cause severe damage to your battery module.




Figure 7-21 Cable connection between adjacent battery module

NOTICE!

- Regarding the making process of power cable, please refer to ["Installation of Female Connector onto Power Cable"](#).
- A corrugated pipe with an external diameter of 60 mm is recommended for use to keep cable insulation in place and avoid potential damages, when conducting wiring between two adjacent battery modules.
- A sound of "Click" should be heard while plugging in the power cables. It indicates that the cable connectors are properly plugged into the ports.
- Don't violently remove the power cables when they are locked.

Step 3: Cover "BAT+" and "BAT-" ports with waterproof plugs (Part E), as well as "BMS" and "COM1" ports with waterproof caps.




Figure 7-22 Left electrical area of the battery module

Tip: Use safety gloves when connecting battery modules.

7.6.2 The Left Electrical Connection Area of the Battery Module Selected to Be Connected to the Inverter

Cable connection for only one battery module

Step 1: Connect the negative power cable to the "BAT-" ports of the battery module and inverter.

Connect the positive power cable to the "BAT+" ports of the battery module and inverter.

Connect the communication cable to the "BMS" ports of the battery module and inverter.

Cover the "COM1" port with a waterproof cap (Part E), and tighten it clockwise.

Ensure that power cables and communication cable are wired correctly, as shown in Figure 7-23. Failing to do so may cause severe damage to the battery module.

Table 7-4 Cable information

Cable	Length	Purpose (from battery module to inverter)	Qty
Communication cable	2000 mm	"BMS" port to "BMS" port	1 pc
Power cable (black)	2000 mm	"BAT-" port to "BAT-" port	1 pc
Power cable (orange)	2000 mm	"BAT+" port to "BAT+" port	1 pc




Figure 7-23 Cable connection of the left electrical connection area

NOTICE!

- Regarding the making process of grounding cable, please refer to "[PE Connection](#)".
- Regarding the making process of communication cable, please refer to "[Communication Connection](#)".
- A sound of "Click" should be heard while plugging in the power cables. It indicates that the cable connectors are properly plugged into the ports.
- The waterproof cap has been covered before delivery.
- Don't violently remove the power cables when they are locked.

Step 2: Cover "BAT+" and "BAT-" ports with waterproof plugs (Part E), as well as "BMS" and "COM1" ports with waterproof caps.




Figure 7-24 Right electrical connection area of the battery module

Tip: Use safety gloves when connecting battery modules.

Cable connection for two or more battery modules

Since the wiring procedure of two battery modules is the same as that of more than two battery modules, the wiring procedure of two battery modules is taken as an example.

The general wiring diagram of two battery modules is shown below:




Figure 7-25 Wiring diagram of two battery module

The detailed connection procedure is shown as follows:

Step 1: Connect the negative power cable to the "BAT-" port of the battery module and inverter.

Connect the positive power cable to the "BAT+" port of the battery module and inverter.

Connect the communication cable to the "BMS" port of the battery module and inverter.

Cover the "COM1" port with a waterproof cap (Part E), and tighten it clockwise.

Make sure that power cables and communication cable are wired correctly, as shown in Figure 7-26. Failing to do so may cause severe damage to your battery module.




Figure 7-26 Cable connection of the left electrical connection area

NOTICE!

- Regarding the making process of grounding cable, please refer to "[PE Connection](#)".
- Regarding the making process of communication cable, please refer to "[Communication Connection](#)".
- A sound of "Click" should be heard while plugging in the power cables. It indicates that the cable connectors are properly plugged into the ports.
- Don't violently remove the power cables when they are locked.

Step 2: Connect the negative power cable to the "BAT-" ports of adjacent battery modules.

Connect the positive power cable to the "BAT+" ports of adjacent battery modules.

Connect the communication cable (Part B1) to the "BMS" ports of adjacent battery modules.

Cover the "BMS" ports of adjacent battery modules with waterproof caps, and tighten them clockwise.

Make sure that power cables and communication cable are wired correctly, as shown in Figure 7-27. Failing to do so may cause severe damage to your battery module.




Figure 7-27 Cable connection of two adjacent battery module

NOTICE!

- Regarding the making process of power cable, please refer to ["Installation of Female Connector onto Power Cable"](#).
- A corrugated pipe with an external diameter of 60 mm is recommended for use to keep cable insulation in place and avoid potential damages, when conducting wiring between two adjacent battery modules.
- A sound of "Click" should be heard while plugging in the power cables. It indicates that the cable connectors are properly plugged into the ports.
- Don't violently remove the power cables when they are locked.

Step 3: Cover "BAT+" and "BAT-" ports with waterproof plugs (Part E), as well as "BMS" and "COM1" ports with waterproof caps.




Figure 7-28 Left electrical connection area of the battery module

Tip: Use safety gloves when connecting battery modules.

8 System Commissioning

8.1 Checking before Power-on

- Check the device installed correctly and securely;
- Make sure that Power button is OFF;
- All cables are connected correctly and securely;
- All unconnected port are covered;

8.2 Powering on/off the System

Power on: Press and hold the POWER button on the right electrical connection area of the battery module that connects to the inverter until the LED lights appear.

Power off: Press and hold the POWER button on the right electrical connection area of the battery module that connects to the inverter until the LED lights go out.




Figure 8-1 Power on/off the system

NOTICE!

- **Regarding the first start, after pressing and holding the POWER button on the battery module that connects to the inverter for 15 seconds, the battery system will assign each battery module in a communication loop a unique address (battery number).** In the meantime, the status light will remain on **solid yellow** for the first **11** seconds and then turn to **solid green**, and the SOC power indicators will remain on **solid blue** based on the battery modules' actual battery capacity. After 15 seconds, the status light will **flash yellow**, and at the same time, release the button. In the meantime, the unique address (battery number) will be assigned. The status light will turn to **flash green** or **solid green** after finishing the address assignment. Then the user can press the button to shut down the system.
- **In the event that the user wishes to increase or reduce the battery modules,** the system must be turned off. After completing the capacity expansion or reduction, press and hold the POWER button for more than 15 seconds to reassign each battery module in communication loop a unique address.
- **Regarding the second start, after pressing the POWER button on the battery module that connects to the inverter for less than 3 seconds,** the status light remains on **solid yellow** for the first **11** seconds and then turns to **solid green**. In the meantime, the SOC power indicators remain on **solid blue** based on the battery modules' actual battery capacity. At this point, release the button.
- A system problem may be encountered while pressing the button frequently. The user may need to wait at least 10 seconds and then try again.

 WARNING!

- After the battery module powers off, there will still be the remaining electricity and heat which may cause electric shocks and body burns. Please wear personal protective equipment (PPE) and begin servicing the battery five minutes after power off.

9 Troubleshooting and Maintenance

9.1 Troubleshooting

This section contains information and procedures for resolving possible problems with the rechargeable battery and provides the troubleshooting tips to identify and solve most problems that may occur. Please conform the state of the indicators to check the status of the T-BAT system, check the warning or fault information via the monitoring software on the inverter, and read the suggested solutions below when error occurs.

In case of the following circumstances, e.g. voltage or temperature exceeds the limit specified, a warning state will be triggered.

The battery management system (BMS) of the T-BAT system will periodically report its operating state to the inverter. Therefore, when a warning is reported, the inverter will stop working immediately.

Contact FRONUS Customer Service for further assistance. Please be prepared to describe the details of your system installation and provide the model and serial number of the rechargeable battery.

Error Code	Fault	Diagnosis and Solution
BMS_CELL_OVER_FAULT	Battery cell overvoltage fault	Battery (cell) overvoltage: • Tap "Power Off" on the inverter screen until the fault is rectified. • Contact the after-sales personnel of our company.
BMS_CELL_LOW_FAULT	Battery cell undervoltage fault	Battery (cell) undervoltage: • Make sure that the inverter is connected to the grid and that there is successful communication between the battery and inverter to ensure that the battery is charged. • Contact the after-sales personnel of our company.
BMS_CELL_DIFF_FAULT	The pressure difference between cells in the battery is too large	The pressure difference between cells in the battery is too large: • Restart the BMS. • Contact the after-sales personnel of our company.

Error Code	Fault	Diagnosis and Solution
BMS_HVB_OVER_FAULT	Total voltage overvoltage fault	Total voltage overvoltage: • Tap "Power Off" on the inverter screen until the fault is rectified. • Contact the after-sales personnel of our company.
BMS_HVB_LOW_FAULT	Total voltage undervoltage fault	Total voltage undervoltage: • Make sure that the inverter is connected to the grid and that there is successful communication between the battery and inverter to ensure that the battery is charged. • Contact the after-sales personnel of our company.
BMS_TEMP_OVER_FAULT	High temperature of the BMS	The temperature of the BMS is too high: • Cool down the BMS to normal temperature, and then restart it. • Contact the after-sales personnel of our company.
BMS_TEMP_LOW_FAULT	Low temperature of the BMS	The temperature of the BMS is too low: • Warm up the BMS to normal temperature, and then restart it. • Contact the after-sales personnel of our company.
BMS_SELF_CHECK_FAULT	Self-test fault of the BMS	Self-test fault of the BMS: • Restart the BMS. • Contact the after-sales personnel of our company.
BMS_PRECHG_FAIL_FAULT	BMS precharge failure fault	External short circuit of the BMS: • Check the external connection and restart the BMS. • Contact the after-sales personnel of our company.
BMS_TEMP_SAMPLE_FAULT	Temperature sampling anomaly	Temperature sampling anomaly: • Restart the BMS. • Contact the after-sales personnel of our company.
BMS_SYS_FAULT	Slave control of abnormal current exists in the system	Slave control of abnormal current exists in the system: • Restart the BMS. • Contact the after-sales personnel of our company.

Error Code	Fault	Diagnosis and Solution
BMS_DSG_OVER_FAULT	Discharge overcurrent of BMS	Discharge overcurrent of BMS: - Restart the BMS. - Contact the after-sales personnel of our company.
BMS_CHG_OVER_FAULT	Overcurrent charging of BMS	Overcurrent charging of BMS: - Restart the BMS. - Contact the after-sales personnel of our company.
BMS_AFE_COM_FAULT	AFE communication fault	AFE communication loss: Contact the after-sales personnel of our company.
BMS_MID_COM_FAULT	The communication between the master and slave is abnormal	The communication between the master and slave is abnormal: - Restart the BMS. - Contact the after-sales personnel of our company.
BMS_VOLT_SENSOR_FAULT	Voltage sensor fault	Voltage sampling fault of the BMS: - Restart the BMS. - Contact the after-sales personnel of our company.
BMS_ID_REPEAT_FAULT	The slave controller with the same number exists in the system.	The slave controller with the same number exists in the system: - Restart "Black Start". - Contact the after-sales personnel of our company.
BMS_CURR_SENSOR_FAULT	Current sensor fault	Current sampling fault of the BMS: - Restart the BMS. - Contact the after-sales personnel of our company.
BMS_LINE_FAULT	The power cable is not properly plugged in.	Improper connection of the power cable: - Rewire the power cables. - Contact the after-sales personnel of our company.
BMS_FLASH_FAULT	Flash fault	Flash fault: Contact the after-sales personnel of our company.
BMS_AFE_PROTECT_FAULT	AFE self-protection failure	AFE self-protection failure: Contact the after-sales personnel of our company.

Error Code	Fault	Diagnosis and Solution
BMS_CHG_REQ_FAULT	Charging request not responded	Inverter does not respond the charging request. - Restart the BMS or the inverter. - Contact the after-sales personnel of our company.
BMS_LOST	Communication loss of the BMS	Communication loss of the BMS: - Ensure that the communication cable is properly connected. - Contact the after-sales personnel of our company.
ALM_ID_BAT_TYPR_CFG_ERR	Error of battery type	Error of battery type: Check whether the communication cable is properly connected after shutting down all the battery modules, and then restart Black Start.
ALM_ID_BATT_VOLT_HIGH	BMS overvoltage	Overvoltage of a single battery module: Contact the after-sales personnel of our company.
ALM_ID_BAT_BMS_CELL_FAULT	Battery cell fault of the BMS	Battery cell fault of the BMS: - Check the fault carefully. - Contact the after-sales personnel of our company.
ALM_ID_BAT_BMS_COMM_FAULT	BMS communication fault	BMS communication fault: - Check the fault carefully. - Contact the after-sales personnel of our company.
ALM_ID_BAT_CURR_HIGH	Battery current too high	Too much current is drawn by a load: - Decrease the load power - Contact the after-sales personnel of our company.
ALM_ID_BAT_SOC_LOW	Low SoC	Low SoC: - Check the fault carefully. - Contact the after-sales personnel of our company.

9.2 Maintenance

Regular maintenance is required for the rechargeable battery. Please pay attention to the following precautions for expressing the optimum device performance. More frequent maintenance service is needed in the worse work environment. Please make records of the maintenance.

Precautions

- If the ambient temperature for storage is between 30°C and 50°C (86°F to 122°F), please recharge the battery modules at least once every 6 months.
- If the ambient temperature for storage is between -20°C and 30°C (-4°F to 86°F), please recharge the battery modules at least once every 12 months.
- For the first installation, the interval among manufacture dates of battery modules shall not be exceed 3 months.
- If a battery module is replaced or added for capacity expansion, each battery's SOC should be consistent. The max. SOC difference should be $\pm 5\%$.
- If users want to increase their battery system capacity, please ensure that the SOC of the existing system capacity is about 40%. The manufacture date of the new battery module shall not exceed 6 months. If the manufacture date of the new one exceeds 6 months, please charge it to around 40%.



WARNING!

- Only qualified person can perform the maintenance for the rechargeable battery.
- Only use the spare parts and accessories approved by FRONUS for maintenance.

10 Decommissioning

10.1 Disassembling the Battery



WARNING!

- Before unplugging the cables, ensure that your hands are dry and free from moisture. This will help prevent electrical shock and ensure a secure grip on the plug.
- When disassembling the battery, strictly follow the steps as below.

NOTICE!

- No matter how many battery modules are installed, the unplugging procedure is the same. For details, refer to the following steps.

Step 1: Press the POWER button to shut down the system before unplugging.




Figure 10-1 Pressing power button

Step 2: Hold down two lock buttons on both sides of the connector firmly to unplug the power cable. Avoid pulling on the cable itself, as this can potentially damage the cable and the port on the battery module.




Figure 10-2 Unplugging power cables

Step 3: Remove the communication cable.




Figure 10-3 Removing communication cable

Step 4: Unscrew the screws counter-clockwise to remove the grounding cable.




Figure 10-4 Removing grounding cable

10.2 Packing

- Load the battery module into the original packing material if possible.
- If the original packing material is not available, you can also use the packing material which meets the following requirements:
 - » Suitable for the weight of product.
 - » Easy to carry.
 - » Be capable of being closed completely.

10.3 Disposing of the Rechargeable Battery

Please dispose of the rechargeable battery or accessories in accordance with the disposal regulations for electronic waste which is applied at the installation site.

11 Technical Data

Parameter Display

Battery Module	TP-LD53
Nominal Voltage (Vdc)	51.2
Operating Voltage (Vdc)	45-58
Nominal Capacity (Ah) ¹	104
Nominal Energy (kWh) ¹	5.32
Usable Energy 90% DOD (kWh) ²	4.7
Max. Output Current (A) ³	100
Peak Charge/Discharge Current (A) ⁴	200 (10 seconds)
Battery Round-trip Efficiency (0.2C, 25°C)	95%
Warranty Period	5 years
Cycle Life 90% DOD (25°C)	6000 cycles
Charge Temperature	0°C ~ 53°C
Discharge Temperature	-20°C ~ 53°C
Storage Temperature	30°C ~ 50°C (6 months); -20°C ~ 30°C (12 months)
Ingress Protection	IP65
Protection Class	I

NOTICE!

1. Test conditions: 100% DOD, 0.2 C charge & discharge @ +25°C.
2. System usable energy may vary with inverter different setting.
3. Discharge: In case of battery cell's temperature range of -20°C ~ 10°C and 45°C ~ 53°C, the discharge current will be reduced;
Charge: In case of battery cell's temperature range of 0°C ~ 25°C and 45°C ~ 53°C, the charge current will be reduced. Product charge or discharge power depends on the actual temperature of the battery cell.
4. The battery can only be discharged and cannot be charged when the battery cell's temperature range is between -20°C and 0°C.

Contact Information



UNITED KINGDOM

Unit C-D Riversdale House, Riversdale
Road, Atherstone, CV9 1FA
+44 (0) 2476 586 998
service.uk@solaxpower.com



AUSTRALIA

21 Nicholas Dr, Dandenong South VIC 3175
+61 1300 476 529
service@solaxpower.com



TURKEY

Fevzi Çakmak mah. aslım cd. no 88 A
Karatay / Konya / Türkiye
service.tr@solaxpower.com



GERMANY

Am Tullnaupark 8, 90402 Nürnberg,
Germany
+49 (0) 6142 4091 664
service.eu@solaxpower.com
service.dach@solaxpower.com



USA

3780 Kilroy Airport Way, Suite 200, Long
Beach, CA, US 90806
+1 (408) 690 9464
info@solaxpower.com



NETHERLANDS

Twekkeler-Es 15 7547 ST Enschede
+31 (0) 8527 37932
service.eu@solaxpower.com
service.bnl@solaxpower.com



POLAND

WARSAW AL. JANA P. II 27. POST
+48 662 430 292
service.pl@solaxpower.com



SPAIN

+34 9373 79607
tecnico@solaxpower.com



ITALY

+39 011 19800998
support@solaxpower.it



BRAZIL

+55 (34) 9667 0319
info@solaxpower.com



PAKISTAN

service.pk@solaxpower.com



SOUTH AFRICA

service.za@solaxpower.com

FRONUS SOLAR ENERGY (WASIQ TRADERS).

Add.: Plot #64&65 FRONUS HOUSE MOULANA SHOUKAT ALI ROAD, BLOCK E, PHASE 1,
JOHAR TOWN, LAHORE PUNJAB 54782

E-mail.: INFO@FRONUS.COM

SALES & SERVICE TEL.: +92 42 111 111 140, +92 42 351 732 22-23-24, +92 42 352 227 54

WWW.FRONUS.COM

